

TD5BNTT TOE TOUCH POP-UP BATH DRAIN INSTALLATION INSTRUCTIONS

Installation of a bath waste can be the most time consuming operation performed by a plumber. Special attention has been given by American Valve® to simplify this job as much as possible. Observe local plumbing codes.

1. Remove the toe touch pop-up(C) and the shoe strainer (D) from the shoe elbow (E). Apply plumber's putty (not included) around the underside flange of the shoe strainer. Align the shoe elbow and the rubber washer (I) under the tub drain hole. Screw the shoe strainer through the tub into shoe elbow. Tighten using pliers or strainer wrench (not included).
2. Place one slip nut (G) and washer (H) on the shoe elbow tube (E) with threads of the slip nuts and beveled edge of the washer facing the end of the tube. Connect the tee (F) to the shoe elbow tube and loosely tighten.
3. Place one slip nut (G) and washer (H) on the overflow tube (A) with threads of slip nut and beveled edge of the washer facing the end of the tube. Place the rubber gasket (B) on the overflow elbow by slipping the edge of the overflow elbow under the connection tabs on the gasket.
4. Insert the overflow assembly (A) into the tee (F) so that the overflow elbow aligns with the overflow hole in the tub.
5. Position the rubber gasket (B) to offset the angle of the tub.
6. Remove tail piece (J), apply plumber's tape (not included) to the threads. Re-install and tighten to the bottom of the tee (F). Connect the threaded tail piece into the floor drain opening.
7. Attach the overflow plate (K) to the overflow elbow (A) using machine screws (L).
8. Re-install the toe touch pop-up (C).
9. Tighten all slip joint connections.
10. Check for leakage by filling the tub with water to the overflow opening.

