

## TD5CRGD TRIP LEVER WASTE INSTALLATION INSTRUCTIONS

Installation of a bath waste can be the most time consuming operation performed by a plumber. Special attention has been given by American Valve® to simplify this job as much as possible. Observe local plumbing codes.

1. Remove the grid (J) and shoe strainer (K) from the shoe elbow (F). Apply plumber's putty or silicone sealant (not included) around the underside flange of the shoe strainer. Align the shoe elbow and the gaskets (G, H) under the tub drain hole. Screw the shoe strainer through the tub into the shoe elbow. Tighten using pliers or strainer wrench (not included).
2. Place one slip nut (E) and washer (D) on the shoe elbow tube (F) with the threads of the slip nut and the beveled edge of the washer facing the end of the tube. Connect the waste tee (B) on the shoe elbow tube and loosely tighten to determine the height of the floor drain.
3. Place the supplied escutcheon (C) over the floor drain pipe.
4. Disconnect the waste tee (B) from the shoe elbow tube (F). Connect the waste tee to the floor drain. Be sure to apply plumber's tape (not included).
5. Connect the shoe elbow tube (F) to the waste tee (B) by tightening the slip nut (E).
6. Install the grid (J) onto shoe strainer (K) using the machine screw (I).
7. Check for leakage by filling the tub with water to the overflow opening.

